

MAINTENANCE CHECK SHEET

LS - Range Rover Sport 2010MY-Onwards

	• TIME (Years)	1	2	3	4	5	6	7	8	9	10	
MAINTENANCE	• MILES (Thousands)	15	30	45	60	75	90	105	120	135	150	
	• KM (Thousands)	24	48	72	96	120	144	168	192	216	240	
• See Passport	to Service for additional inform	natio	n									
1. VEHICLE INTERIOR												
Reset Service Interval and Engine Oil Level indicators												
Check operation of all lights, warning indicators and horn												
Check operation of front / rear wiper washer systems; inspect												
blades												
Check operation of electric park brake												
Check condition and security of seats and seat belts												
2. VEHICLE EXTERIOR												
Check all tire pressures, co	ndition, and tread depth											
3. ENGINE COMPARTMI	ENT	_										
Check battery condition, fill	electrolyte, clean terminals											
	AS, Dynamic Response and windshield		_	_	_	_	_		_	_	_	
washer fluid												
Check engine coolant level	and freeze protection level											
Inspect drive belt(s)	<i>eu</i>											
	Replace engine oil and replace filter											
	Replace pollen filter											
Replace air-cleaner elements - Supercharged * Replace air-cleaner elements - Naturally Aspirated *												
Replace brake fluid *		Every 3 years										
Replace spark plugs *		Every 105,000 mi / 168,000 km										
Replace accessory drive belt - with Dynamic Response *		Every 105,000 mi / 168,000 km										
Replace Supercharger drive belt *		Every 105,000 mi / 168,000 km										
Replace accessory drive belt - without Dynamic Response *		Every 150,000 mi / 240,000 km										
Replace engine coolant *		Eve	ery 10	years								
4. UNDER VEHICLE												
Check for fluid leaks												
Check condition / operation	Check condition / operation of suspension and steering components, boots, and drive axles											
Check brake, fuel, PAS and	Dynamic Response lines / hoses / sses for correct routing and damage											
Remove any debris from be and body	etween Dynamic Response valve block											
Remove road wheels; lubrid	cate wheel centers											
Inspect for brake pad wear,	Inspect for brake pad wear, caliper leaks and disc condition											
Install road wheels to opposite side of the vehicle - except uni-directional tires, which install on same side												
	e valve block filter; top up fluid level											
	Replace transfer case fluid; replace drain and fill plug washers *											
Replace locking differential fluid *												
Replace flexible brake hoses *			Every 6 years									
Replace front and non-locking rear differential fluid * Every 10 years Replace fuel filter * Every 10 years / 150,000 mi / 240,000 km												
	Replace automatic transmission fluid and filter *				Every 10 years / 150,000 mi / 240,000 km							
	ERVICE CAMPAIGN NEEDED			Jouro ,	100,00							
Check for open Service Ca												
If fault lamps illuminated us	e IDS to find the faults and report											
6. ROAD TEST												
	Select LOW range; move vehicle 60 ft (18 m); select HIGH range											
Road test vehicle												
Record performance of Ser	Record performance of Service in Passport to Service											

* Labor cost not included in scheduled time

NOTIFICATION OF SERVICE REQUIREMENTS:

• Please refer to your Owner's Manual for Service Recommendations if your vehicle is used extensively off-road or under severe conditions.

• The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.





Loaded I/M testing of permanent four-wheel drive or traction control-equipped vehicles must be conducted on a four-wheel drive synchronized dynamometer. Otherwise, a non-loaded test procedure must be followed.

→ NOTE: Some items do not need to be carried out at every service. All required steps in a specific service are identified in the column headed by the mileage / month by a check box (□).

IMPORTANT

CAUTION: Should a Range Rover Sport vehicle have a high proportion of short journeys or operate in severe conditions, Land Rover recommends that the maintenance intervals be cut in half for 'Arduous Use'

For Arduous Use: at the least the following precautions must be observed:

- After 50 mi / 80km of continuous use in severe off-road conditions wading, deep mud, and abrasive grit / slurry – the electric park brake should be inspected, cleaned, and adjusted. The serpentine engine drive belts should also be inspected and cleaned.
- If a vehicle is used extensively in arduous / off-road conditions, the road wheel speed sensors, brake pads, and brake calipers should be checked for abrasive wear every 1,000 mi / 1,500 km.
- When the vehicle is used in dusty or off-road conditions or is subjected to deep wading, more frequent replacement of the air cleaner elements may be required.

For full details regarding the operations contained in this maintenance check sheet, please refer to the Workshop Manual (GTR).

	L / F:	R / F:			
TIRE TREAD DEPTH (including spare)	L / R:	R / R:			
	SPARE:				

Comments / Remedial Action Required

Please refer to your Owner's Manual for Service Recommendations if your vehicle is used extensively off-road or under severe conditions.

• The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.