



# MAINTENANCE SCHEDULE

2006 -2009 Range Rover Sport

Owner's Name: \_\_\_\_\_

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_ RO#: \_\_\_\_\_

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	A	O&F	B	O&F	A	O&F	B
	TIME (Months)	6	12	18	24	30	36	42	48
	⊕ MILES (Thousands)	7.5	15	22.5	30	37.5	45	52.5	60
	⊕ KM (Thousands)	12	24	36	48	60	72	84	96
⊕ See Passport to Service for additional information.									
<b>1. VEHICLE INTERIOR</b>									
Reset the Service Interval Indicator		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation of front / rear wiper washer systems; check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
<b>2. VEHICLE EXTERIOR</b>									
Anti-corrosion check. Use <b>Corrosion Perforation Form</b>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect and lube door checks; inspect hood latch and fuel flap			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
<b>3. ENGINE COMPARTMENT</b>									
Inspect serpentine drive belt			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect oil cooler; remove debris (Supercharged)			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid ( <b>3 years</b> )							<input type="checkbox"/>		
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace air-cleaner element									<input type="checkbox"/>
<b>4. UNDER VEHICLE</b>									
Change engine oil and replace filter		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Remove road wheels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for brake pad wear, caliper leaks and disc condition			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tire pressures condition and tread depth			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check adjustment of electric parking brake			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate wheel centers			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Install road wheels to opposite side of the vehicle – <b>except uni-directional tires which install on same side</b>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for under vehicle fluid leaks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check exhaust system for leaks and damage			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Remove debris from Dynamic Response valve block and chassis			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace Dynamic Response valve block filter									
Inspect condition and operation of suspension and steering components, boots and driveshafts					<input type="checkbox"/>				<input type="checkbox"/>
Check torque of tie rod ends; tighten to 76 Nm (56 lbf ft)			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect brake, fuel lines, PAS hoses and unions					<input type="checkbox"/>				<input type="checkbox"/>
Inspect electrical harnesses for correct routing and damage					<input type="checkbox"/>				<input type="checkbox"/>
<b>5. REMEDIAL WORK / SERVICE CAMPAIGN NEEDED</b>									
If fault lamps are illuminated use IDS to find the faults and report	Yes/No	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<b>6. ROAD TEST</b>									
Select LOW range, move vehicle 60 ft (18m), select HIGH range			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Road test vehicle			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Record performance of Service in Passport to Service		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

\* Labor cost not included in scheduled time.

**NOTIFICATION OF SERVICE REQUIREMENTS:**

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.



# MAINTENANCE SCHEDULE

2006 -2009 Range Rover Sport

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	A	O&F	B	O&F	A	O&F	B
	TIME (Months)	54	60	66	72	78	84	90	96
	⊙ MILES (Thousands)	67.5	75	82.5	90	97.5	105	112.5	120
	⊙ KM (Thousands)	108	120	132	144	156	168	180	192
⊙ See Passport to Service for additional information.									
<b>1. VEHICLE INTERIOR</b>									
Reset the Service Interval Indicator		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation of front/rear wiper washer systems; check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
<b>2. VEHICLE EXTERIOR</b>									
Anti-corrosion check. Use <b>Corrosion Perforation Form</b>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect and lube door checks; inspect hood latch and fuel flap			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
<b>3. ENGINE COMPARTMENT</b>									
Check battery condition, fill electrolyte, clean terminals			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect serpentine drive belts			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace serpentine drive belts ( <b>Dynamic Response - 105k mi</b> )							<input type="checkbox"/>		
Replace serpentine drive belt ( <b>non-Dynamic Response - 150k mi</b> )	<b>At 150,000 miles / 240,000 kilometers</b>								
Replace Supercharger drive belt ( <b>if equipped - 105k mi</b> )							<input type="checkbox"/>		
Inspect oil cooler, remove debris			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid ( <b>3 years</b> )					<input type="checkbox"/>				
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change engine coolant ( <b>10 years</b> )									<input type="checkbox"/>
Replace spark plugs ( <b>at 105k miles</b> )							<input type="checkbox"/>		
Replace air-cleaner element									<input type="checkbox"/>
<b>4. UNDER VEHICLE</b>									
Change engine oil and replace filter	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Remove road wheels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for brake pad wear, caliper leaks and disc condition			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tire pressures condition and tread depth			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check adjustment of electric parking brake			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate wheel centers			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Install road wheels to opposite side of the vehicle – <b>except uni-directional tires which install on same side</b>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for under vehicle fluid leaks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check exhaust system for leaks and damage			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect steering ball joints for wear, damaged dust covers					<input type="checkbox"/>				<input type="checkbox"/>
Remove debris from Dynamic Response valve block and chassis			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace Dynamic Response valve block filter			<input type="checkbox"/>						
Inspect condition and operation of suspension and steering components, boots and driveshafts.					<input type="checkbox"/>				<input type="checkbox"/>
Check torque of tie rod ends; tighten to 76 Nm (56 lbf ft)			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect brake, fuel lines, PAS hoses and unions					<input type="checkbox"/>				<input type="checkbox"/>
Inspect electrical harnesses for correct routing and damage					<input type="checkbox"/>				<input type="checkbox"/>
Replace flexible brake hoses ( <b>6 years</b> ) *					<input type="checkbox"/>				
Change automatic transmission fluid and filter ( <b>10 years</b> )									<input type="checkbox"/>
Change transfer gearbox oil ( <b>75k and 150k miles</b> )			<input type="checkbox"/>						
Change front and rear axle oil ( <b>10 years</b> )									<input type="checkbox"/>
Change locking differential oil ( <b>75k and 150k miles</b> )			<input type="checkbox"/>						
<b>5. REMEDIAL WORK / SERVICE CAMPAIGN NEEDED</b>									
If fault lamps are illuminated use IDS to find the faults and report	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<b>6. ROAD TEST</b>									
Select LOW range, move vehicle 60 ft (18m), select HIGH range			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Road test vehicle			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Record performance of Service in Passport to Service	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

\* Labor cost not included in scheduled time.

#### NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.

